



## JEEP JK CLASS III - 2" RECEIVER HITCH

Thank you for choosing Rough Country for all your suspension needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

To install this receiver hitch you will need a 18mm wrench to remove the OEM tow hook, if equipped, and a 5/8" wrench.

### IMPORTANT INFORMATION:

Do not exceed 2,000 lbs factory towing capacity of the Jeep JK and do not exceed a maximum tongue weight of 350 lbs.

RC Receiver Hitch for Jeep JK



7/16" 4.5" Long Bolt (4)

Not Shown—7/16" Lock Washer (4)

### INSTALLATION INSTRUCTIONS

1. **For vehicles equipped with OEM Tow Hook:** Remove the factory hardware securing the factory hook with a 18mm wrench. Remove the tow hook bracket. **See Figure 1.** Use caution to make sure muffler is not hot.
2. Install the new Rough Country bracket in the same location as the stock bracket was removed and using the 4 supplied 7/16 bolts, lock washers as shown in **Figure 2.** The new bracket will utilize 4 of the factory holes in the frame as the stock bracket only used 3. Tighten hardware to 50 ft/lbs.

Figure 1

Removing OEM Tow Hook



Figure 2

Installing Class III Receiver Hitch

